## **Golf Swing Trainer GST2020 Manual** v1.0

## Setup and Use

- Download Android app from GolfSwingTrainer.ca and install-open app.
- Swing the stick a few times to turn it on.
- Go to the Setup screen to change parameters and press Done to return to main screen.
- Swing the stick and hold still for one second for it to display or readout results.
- Do not swing the stick for 90 seconds to turn it off.

## Application

Swing
6= 101 MPH 3.2 Temp
5= 97 MPH 3.1 Tempo

- 4= 92 MPH 2.7 Tempo
- 3= 92 MPH 3.1 Tempo
- 2= 93 MPH 3.2 Tempo
- 1=83 MPH 3.2 Tempo

Setup		
Setup		
Speak Results:	•	
Sensor Address:	F0:13:8C:E1:D7:5A	
Radius Sensor (in):	55	
Radius Club (in):	61	
Battery (%):	88	
F0:13:8C:E1:D7:5A	Set Sensor Address	

- The swing speed and tempo are displayed for each swing of the club over 30mph.
- Press Setup to change the configurable parameters.
- Set your device display to always on while using.

- Check Speak Results to use speech readout option.
- Enter \* for Sensor Address to match all nearby sensors or press Set Sensor Address to select the found nearby sensor address.
- Radius Sensor is the distance from chest to sensor.
- Radius Club is the distance from chest to end of club you want measurement for.
- Current Battery level is displayed as percentage full.
- Press Done to save and return to main screen.

## Maintenance

Done

• If the battery percentage is low, or if Set Sensor Address does not appear on the setup screen after a few swings, remove two screws on sensor to replace CR2032 battery.

© Gorko Systems Inc.